


## Popular BMW D 35 & D50 parts

Fuel filter	1332	1329	270
Air FilterD35	1372	1329	294
Air filter D50	1372	1257	060
Oil Filter	1142	1761	087
Impeller kit	1711	1331	424
Anode	1711	1329	197
Head gasket D35	1112	1331	566
Valve grind set D35	1100	1761	134
Head gasket D50	1112	1331	559
Valve grind set D50	1100	1761	135
Injector	1353	1333	124
Injector seat	1353	1331	561
Lift (fuel) pump	1331	1333	013
Raw water pump	1711	1333	640
Coolant pump	1151	1333	330
Oil Cooler kit D50	1721	1329	339
Starter ** NEW	1241	1329	906
Alternator 75 Amp	1231	1333	935
V-Belt (-1)	1231	1331	436
V-Belt (-2)	1231	1333	332
Exhaust Pipe (-2)	1162	1333	344
Thermostat ( -1 )	1711	1329	391
Thermostat ( -2 )	1153	1328	591
Rings STD	1125	1331	848
Rings O/S	1125	1333	137
Parts catalogue	0109	2128	039
Owners manual English	0140	2128	005
Owners manual French	0140	2128	005F
Workshop manual English	0151	2128	313
Workshop manual French	0151	2128	314 F



1100 1761 134 D50 gasket set.jpg



1151 1333 330 D50 2 Coolant pump.jpg



1153 1333 323 D35 tank 022.jpg



1162 1333 344 D50-2 Exhaust pipe new .JPG



1214 1333 921 B pin type stop solenoid .jpg



1231 1333 935; REBUILT A.JPG



1241 1329 906 D50 starter .jpg



1711 1329 197 Anode and bolt (1).JPG



1711 1329 197 Anode and bolt .JPG




1711 1333 640 A.JPG



1721 1329 339.JPG



7461 1333 742 On Board Kit.jpg



D50-2 Abigale left.jpg



D50-2 Left side.jpg



manifold AR.JPG



Picture 003.jpg